



How do I clean a QUARE Baths and Totems?

It should be cleaned with water after each use. It is essential to ventilate the bathroom every day to ensure good ventilation.

Our **Baths and Podium totems** are made of Q-TEK (Solid Surface).

Cleaning is EASY, SIMPLE and ECO-FRIENDLY:

- Use a clean, damp, non-abrasive sponge to scrub the entire surface and then rinse thoroughly,
- We recommend simply using water and:
 - Liquid detergent or soap (ideally pH neutral soap).
 - The white "magic" sponge. (Also used to clean pool liners).
 - White vinegar for domestic use (3 cups of white vinegar diluted in half a litre of water). Leave to act for 30 minutes.
 - Less ecological: Specific anti-limescale products for domestic use. Leave to act for 10 to 15 minutes.

For cleaning, aggressive chemical products such as acetone, trichloroethylene, strong acids (muriatic acid, etc.) as well as strong bases (caustic soda, etc.), industrial detergents and solvents used in the paint industry are **NOT RECOMMENDED**. For further information, please refer to the enclosed instructions on the care and maintenance of the product.

- **DO NOT** use metal scrapers, iron brushes or other metal household tools to remove stains, paint, putty, etc.
- Some substances such as ink, cosmetics and dyes, if left in contact with the surface of the Bath for a long time, can stain the material; the same can happen with lit cigarettes.